


PROGRESSIVE DYNAMICS DC DISTRIBUTION PANEL

FRONT OF DC PANEL



This panel uses standard automotive blade-style fuses for each branch circuit. These fuses aren't included because they are widely available and the amp rating will vary depending on your loads. Generally you should fuse for 5A-10A above the maximum current that will flow through the circuit during normal operation.

BACK OF DC PANEL

